



NOTES:

1. PROPER BACKFLOW PROTECTION REQUIRED BY ARIZONA AMERICAN WATER.
2. USER MUST INSTALL A REDUCED PRESSURE PRINCIPLE BACKFLOW PREVENTION ASSEMBLY ON EACH HYDRANT METER BEFORE USING WATER.
3. BACKFLOW ASSEMBLY MUST BE TESTED BY A RECOGNIZED, CERTIFIED BACKFLOW ASSEMBLY TESTER BEFORE USING AND ALSO EACH TIME METER IS MOVED.
4. USER MUST REMOVE BACKFLOW ASSEMBLY WHEN HYDRANT METER IS REMOVED OR RELOCATED.
5. USER IS LIABLE FOR ANY DAMAGE TO HYDRANT METER AND FITTINGS.
6. CALL 823-445-2421 FOR QUESTIONS.
7. USER MUST USE GATE VALVE TO CONTROL FLOW OF WATER.

DATE:

7/15/05



Arizona
American Water

19820 N. 7th Street, Suite 201
Phoenix, AZ. 85024 (623) 445-2400

RWE GROUP

REDUCED PRESSURE PRINCIPLE BACKFLOW PREVENTION ASSEMBLY

FOR TEMPORARY USE ON HYDRANT METERS

DETAIL